

TANK MUST SOLARBEAT™

USER GUIDE

FOR WATCHES SOLD
AFTER THE 1ST NOVEMBER 2024

Cartier

TABLE OF CONTENTS

1

**WHAT IS THE
SOLARBEAT™ MOVEMENT?**

page 3

2

**MY WATCH IS ON TIME,
HOW SHOULD I CHARGE IT?**

page 4

3

**HOW LONG DOES IT TAKE
TO CHARGE MY WATCH?**

page 5

4


**MY WATCH HAS STOPPED WORKING,
HOW SHOULD I RESTART IT?**

page 6

5


**HOW DOES THE
WARRANTY WORK?**

page 7



WHAT IS THE SOLARBEAT™ MOVEMENT?

A MOVEMENT POWERED BY PHOTOVOLTAIC ENERGY



WHAT IT IS

The SolarBeat™ movement is Swiss made and powered by photovoltaic energy, meaning that the battery of the watch recharges when exposed to daylight and artificial light. The photovoltaic movement watch can work for at least 16 years without battery replacement, versus 8 years for the high-autonomy quartz movement, and 3 years for a classic quartz movement.

HOW IT WORKS

The SolarBeat™ photovoltaic movement works with both natural and artificial light. The perforated dial allows light to reach the photovoltaic cell underneath.

The battery storing the energy will recharge more or less rapidly depending on the exposure to light.

AUTONOMY

When fully charged, the battery has an autonomy of about 24 months. Be aware that the watch should be frequently exposed for better efficiency and to ensure normal behaviour of the battery.

MY WATCH IS ON TIME, HOW SHOULD I CHARGE IT?

HOW TO CHARGE YOUR WATCH

We recommend exposing the watch to direct sunlight in outdoor conditions for at least 2 hours per month, with the dial facing the source of light, to ensure optimal and complete charging of the battery.*



The dial must be facing towards the source of light



HOW TO AVOID FULLY DISCHARGING THE BATTERY

WHEN WEARING THE WATCH

→ *Make sure it is not always entirely covered by your sleeves (the battery will recharge proportionately to the dial's light exposure).*

WHEN NOT WORN

→ *Leave the watch in a space exposed to light as much as possible.*

**Please refer to the charging table on page 5 for the approximate charging time of your watch depending on the environment you are in.*

SUITABLE ENVIRONMENTS

Charging works with both natural and artificial light.

1

OUTDOORS


Depending on the weather, recharging the battery may be less efficient.



2

INDOORS

Place the watch behind a window with the dial facing the light.



3

ARTIFICIAL LIGHTING

Place the watch under a lamp - depending on the distance, the recharge may be less efficient.



HOW LONG DOES IT TAKE TO CHARGE MY WATCH?

PLEASE REFER TO THE TABLE BELOW FOR THE APPROXIMATE CHARGING TIME OF YOUR WATCH DEPENDING ON THE ENVIRONMENT YOU ARE IN.

ENVIRONMENT	MINIMUM EXPOSURE FOR 1 DAY OF AUTONOMY		MINIMUM EXPOSURE TO RESTART THE WATCH		EXPOSURE FOR A 5-MONTH RECHARGE OF THE BATTERY	
	V1*	V2**	V1*	V2**	V1*	V2**
OUTDOORS SUNNY	4 min	2 min	1 hr	0.5 hr	9 hrs	5 hrs
OUTDOORS CLOUDY	12 min	8 min	2 hrs	1 hr	29 hrs	18 hrs
INDOORS LAMP AT 20 CM	27 min	15 min	4 hrs	2 hrs	68 hrs	37 hrs
OUTDOORS VERY CLOUDY	67 min	32 min	12 hrs	6 hrs	167 hrs	78 hrs
INDOORS SHOPPING CENTRE	112 min	48 min	-	-	280 hrs	120 hrs

CAUTION

Please do not charge the watch at high temperatures ($>60^{\circ}\text{C}$), as this may damage the components inside.

*purchased prior to November 1st 2024


**purchased on/after November 1st 2024

Please note that this table shows the approximate charging times when the watch is continuously exposed to light. If the watch is partially charged for less than the recommended time in the table above, the movement will continue to run for a shorter period of time and then stop when the battery is too low.

MY WATCH HAS STOPPED WORKING, HOW SHOULD I RESTART IT?

BE AWARE THAT IF THE WATCH IS NOT REGULARLY EXPOSED TO LIGHT, THE BATTERY WILL START DISCHARGING AND EVENTUALLY STOP WORKING.

FOLLOW THE STEPS BELOW TO RESTART THE WATCH



CAUTION

When fully discharged, the battery requires at least 1 hour* to restart (*or more depending on the source of light's power, see the Charging Table on page 5).
When restarted, the battery is at its minimum battery level for operation.
To increase the battery autonomy, extend the exposure for 9 hours to direct sunlight until the battery is fully charged (see the Charging Table on page 5 to check the corresponding time in other conditions).

HOW DOES THE WARRANTY WORK?

CARTIER INTERNATIONAL WARRANTY

As with any Cartier timepiece, your watch is covered by the Cartier International Warranty for a period of 2 years from the date of purchase. Please find additional details on your local Cartier website.

WARRANTY EXTENSION

You can extend this warranty up to 8 years, as well as benefit from personalised communications and services, by registering your watch with Cartier Care [here](#).

ABNORMAL BEHAVIOUR

In case of any abnormal behaviour of the watch, please check the Cartier website to find the closest Boutique, Retail Partner, or Call Center on cartier.com.



Cartier